


**DAIKIN**




# INSTALLATION AND OPERATION MANUAL

**Option kit for combination of Daikin  
condensing units with field supplied air  
handling units**


EKEQFCBV3  
EKEQDCBV3




1 **EKEQFCBV3**




2 **EKEQDCBV3**




3 **EKEQFCBV3**



4 **EKEQFCBV3**



5 **EKEQDCBV3**



6 **EKEQDCBV3**

CE - DECLARATION-OF-CONFORMITY  
 CE - KONFORMITÄTSSERKLÄRUNG  
 CE - DECLARATION-DE-CONFORMITE  
 CE - CONFORMITEITS/VERKLARING

CE - DECLARACION-DE-CONFORMIDAD  
 CE - DICHIARAZIONE-DI-CONFORMITA  
 CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ

CE - DECLARACIÓN-DE-CONFORMIDADE  
 CE - ЗАРЯВЛЕНИЕ-О-СООТВЕТСТВИИ  
 CE - OPEYDELSERKLARING  
 CE - FÖRSÄKRAN-OM-ÖVERENSSTÄMMELSE

CE - ERKLÄRUNG OM-SAMSVAR  
 CE - ILMOITUS-YHDENMUKAISUDESTA  
 CE - DEKLARACJA-ZGODNOSCI  
 CE - DECLARAȚIE-DE-CONFORMITATE

CE - IZJAVA O USKLABENOSTI  
 CE - MEGFELELŐSÉG-NYILATKOZAT  
 CE - DEKLARACIJA-ZGODNOSCI  
 CE - DECLARAȚIE-DE-CONFORMITATE

CE - IZJAVA O SKLADNOSTI  
 CE - VASTAVUSDEKLARACIJA  
 CE - VYHLÁSENIE-ZHODY  
 CE - UYUMLULUK-BİLDİRİŞİ

CE - ATTIKITES-DEKLARACIJA  
 CE - ATBLISTBAS-DEKLARACIJA  
 CE - VYHLÁSENIE-ZHODY  
 CE - UYUMLULUK-BİLDİRİŞİ

## Daikin Europe N.V.

- 01 (GB) déclare under its sole responsibility that the air conditioning equipment to which this declaration relates:
- 02 (E) erklärt auf seine alleinige Verantwortung dass die Ausüstung der Klimaanlage für die diese Erklärung bestimmt ist:
- 03 (F) déclare sous sa seule responsabilité que l'équipement d'air conditionné visé par la présente déclaration:
- 04 (NL) verklaart hierbij op eigen exclusieve verantwoordelijkheid dat de airconditioningapparatuur waarop deze verklaring betrekking heeft:
- 05 (E) declara bajo su única responsabilidad que el equipo de aire acondicionado al que hace referencia la declaración:
- 06 (I) dichiara sotto la propria responsabilità che gli apparecchi di condizionamento a cui le riferita questa dichiarazione:
- 07 (GR) δηλώνει αποκλειστική της ευθύνη ότι ο εξοπλισμός των κλιματιστικών συσκευών στο οποίο αναφέρεται η παρούσα δήλωση:
- 08 (P) declara sob sua exclusiva responsabilidade que os equipamentos de ar condicionado a que esta declaração se refere:

EKEQDCBV3\*, EKEQFCBV3\*,  
 \* = . 1. 2. 3. .... 9

- 01 are in conformity with the following standard(s) or other normative document(s), provided that these are used in accordance with our instructions:
  - 02 der/den folgenden Norm(en) oder einem anderen Normdokument oder -dokumenten entsprich(t)en/sprechen, unter der Voraussetzung, daß sie gemäß unseren Anweisungen eingesetzt werden:
  - 03 sont conformes à la(s) norm(e)(s) autre(s) document(s) normatif(s), pour autant qu'ils soient utilisés conformément à nos instructions:
  - 04 conform de volgen de norm(en) of één of meer andere bindende documenten zijn, op voorwaarde dat ze worden gebruikt overeenkomstig onze instructies:
  - 05 están en conformidad con la(s) siguiente(s) norma(s) u otro(s) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras instrucciones:
  - 06 sono conformi alle seguente(i) standard(i) o altro(i) documento(i) a carattere normativo, a patto che vengano usati in conformità alle nostre istruzioni:
  - 07 είναι σύμφωνα με τις οδηγίες μας, σύμφωνα με το/α ακόλουθ(ο) προνομ(ο) ή άλλο έγγραφο(ο) κανονισμών, υπό την προϋπόθεση ότι χρησιμοποιού(ν)τα σύμφωνα με τις οδηγίες μας:
- EN60335-2-40,
- 10 under kapitajelse af bestemmelserne i:
  - 11 enligt vilkoren i:
  - 12 gilt i henhold til bestemmelserne i:
  - 13 nouădateați în condițiile următoare:
  - 14 za doobrenje ustanovljeni predpisi:
  - 15 prema odredbama:
  - 16 követeli a(z):
  - 17 zgodnie z postanowieniami Dyrektywy:
  - 18 in urma prevederilor:

- 01 Note\* as set out in <A> and judged positively by <B>
- 02 Hinweis\* wie in der <A> aufgeführt und von <B> positiv beurteilt gemäß Zertifikat <C>
- 03 Remarque\* tel que défini dans <A> et évalué positivement par <B> conformément au Certificat <C>
- 04 Bemerk\* zoals vermeld in <A> en positief beoordeeld door <B> overeenkomstig Certificaat <C>
- 05 Nota\* como se establece en <A> y es valorado positivamente por <B> de acuerdo con el Certificado <C>

- 11 Information\* enigi <A> och godkänns av <B> enligt Certifikat <C>
- 12 Merk\* som del fremkommer i <A> og godkenn positivt i henhold til <B> i henhold til <C>
- 13 Huom\* jolla on esitetty asiainpöytä <A> ja jotka <B> on hyväksynyt Sertifikaatissa <C> mukaisesti
- 14 Poznámka\* jak bylo uvedeno v <A> a pozitivně zjišeno <B> v souladu s osvědčením <C>
- 15 Napomena\* kako je izloženo u <A> pozitivno ocijenjeno od strane <B> prema Certifikatu <C>

- 16 Megjegyzás\* a(z) <A> alapján, a(z) <B> igazolta a megfélekt, a(z) <C> tanúsítvány szerint.
- 17 Uwaga\* zgodnie z dokumentacją <A> pozytywną opinią posiada aw <B> i zgodnie z <C>
- 18 Noia\* asa cum este stabilit in <A> si anexat pozitiv in <B> si conformitate cu Certificatul <C>
- 19 Opomba\* kot je dobljeno v <A> in odobreno s strani <B> skladu s osvedceno <C>
- 20 Märkus\* naku je izloženo u <A> pozitivno ocijenjeno od strane <B> prema Certifikatu <C>

- 21 Zabeleška\* kartu e voprečno v <A> u ocenjeno pozitivno od <B> v skladu s osvedčenjem <C>
- 22 Pastaba\* kap nustatyta <A> ir kaip teigiama nuspreta <B> pagal Sertifikaat <C>
- 23 Pezámus\* ká nrdádis <A> u atbilstoš <B> pozitívajam vērdējumam saskaņā ar sertifikātu <C>
- 24 Poznámka\* ako bolo uvedené v <A> a pozitivne zistené <B> v súlade s osvedčením <C>
- 25 Not\* <A> za bejtirrtégi gbi, ve <C> Sertifikasima görge <B> taradindan olumlu olarak deđerlendirildi gbi.

- 17 (PL) deklaruję na własną i wyłączną odpowiedzialność, że klimatyzatory, których dotyczy niniejsza deklaracja:
- 18 (GB) declare for proprio răspundere că echipamentele de aer condiționat la care se referă această declarație:
- 19 (HU) zviso odgovorností zjavím, že je opera klimatiských naprav, na ktoré sa zjavá nadoz.
- 20 (ET) kinnitan oma läheku vastutusele, et käesoleva deklaratsiooni alla kuuluv kliimasüsteemide varustis:
- 21 (BG) декларирам на свое отговорност, че оборудването за климатизацията, на което се отнася тази декларация:
- 22 (LT) viskisa savo atsakomybės sietiaba, kad oro kondicionavimo įranga, kuriai taikoma ši deklaracija:
- 23 (LV) ar pilnu atbildību apliecinu, ka šīs uzskaitlības gaisa kondicionēšanas iekārtas, uz kurām attiecas šī deklarācija:
- 24 (SK) vyhlasuji na vlastnu zodpovednosť, že klimatizačné zariadenie, na ktoré sa vzťahuje toto vyhlasenie:
- 25 (TR) lanamem kendi sorumluluğunda olmak üzere bu bildirimni ilgili oluğu klima donaniminin asagidaki gibi oldugunu beyan eder:

- 16 megfelelenek az alábbi szabvány(ok)nak vagy egyéb irányadó dokumentum(ok)nak, ha azokat előírás szerinti hasznájjak:
- 17 spełniaj wymogi następujących norm i innych dokumentów normalizacyjnych, pod warunkiem że używane są zgodnie z naszymi instrukcjami:
- 18 sunt în conformitate cu următor (urmatorele) standarde (sau alte) documente (normative), cu condiția ca acestea să fie utilizate în conformitate cu instrucțiunile noastre
- 19 skladaju se naslednjih standardi in drugih normativi, pod pogojem, da se uporabljajo v skladu z našimi navodili:
- 20 kon vastavus järgmist (ie) standard(ide)ga või teiste normatiivsete dokumentidega, kui need kasutatakse vastavalt meie juhendile:
- 21 съответстват на следните стандарти или други нормативни документи, при условие, че се използват съгласно нашите инструкции:
- 22 atitinka žemiau nurodytus standartus ir (arba) kitus norminius dokumentus su sąlyga, kad yra naudojami pagal mūsų nurodymus:
- 23 tad, ja leliti atbilstoš (ie) standarta (id) norādījumiem, atbilst sekojošiem standartiem un citiem normatīviem dokumentiem:
- 24 sú v zhode s nasledovnými (ými) normou (ami) alebo inými (i) normatívnymi (i) dokumentami (ami), za predpokladu, že sa používajú v súlade s našimi návodmi:
- 25 inünin, laimatalarmaz göre kulanılması kosullariya asagidaki standartlar ve norm belirlen belgelerle uyumludur:

## EN60335-2-40,

- 10 Direktiver, med senere ændringer.
- 11 Direktiv, med följande ändringar.
- 12 Direktiver, med forsatte ændringer.
- 13 Direktiveja, seilaisia kuin ne ovat muuttelutina.
- 14 plátienm znení.
- 15 Smernice, kako je izmjenjeno.
- 16 irányelvek és módosítások rendelkezését.
- 17 z pöriznejšimi popravkami.
- 18 Direktivelor, cu amendamentele respective.

- 01 Direktives, as amended.
- 02 Direktiven, cernat Änderung.
- 03 Direktives, telles que modifiées.
- 04 Richtlijnen, zoals gearmeenderd.
- 05 Directivas, según lo emendado.
- 06 Direktive, kako je izmjenjeno.
- 07 Önyvök, omuk, éyov, pörizomótéi.
- 08 Direktivas, conforme alteraçáo em.
- 09 Direktive cu vesmi popravkami.

## Low Voltage 2006/95/EC \* Electromagnetic Compatibility 2004/108/EC \*



CONTENTS

Page

**Introduction ..... 1**

**Installation ..... 2**

Accessories ..... 2

Name and function of parts ..... 2

Before installation ..... 2

Selecting the installation site ..... 3

Valve kit installation ..... 4

Installation of the electrical control box ..... 5

Electric wiring work ..... 5

Installation of thermistors ..... 8

Refrigerant piping work ..... 9

Test operation ..... 9

**Operation and maintenance ..... 9**

What to do before operation ..... 9

Operation and display signals ..... 11

Troubleshooting ..... 11

Maintenance ..... 12

Disposal requirements ..... 12

INTRODUCTION



- Do only use this system in combination with a field supplied air handling unit. Do not connect this system to other indoor units.
- Only optional controls as listed in the optional accessories list can be used.

We distinguish 2 different control boxes, each with its own application and installation requirements.

- EKEQFCB control box (2 possible operation modes)
  - Operation with 0–10 V input to control the capacity  
An external controller is needed to control the capacity. For details of the necessary functions of the external controller refer to paragraph "Operation with 0–10 V capacity control" on page 10. It can be used to control the room temperature or air discharge temperature.
  - Operation with fixed  $T_e/T_c$  temperature control
    - In cooling this system operates on a fixed evaporating temperature.
    - In heating this system operates on a fixed condensing temperature.
- EKEQDCB control box  
The system will operate as a standard indoor unit to control the room temperature. This system does not require a specific external controller.
- Do NOT connect the system to DIII-net devices:
  - **Intelligent<sup>touch</sup> Controller**
  - **Intelligent Manager**
  - **DMS-IF**
  - **BACnet Gateway**
  - ...

This could result in malfunction or breakdown of the total system.
- This equipment is not designed for year-round cooling applications with low indoor humidity conditions, such as Electronic Data Processing rooms.
- This appliance is not intended for use by persons, including children, with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.  
Children should be supervised to ensure that they do not play with the appliance.



READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION AND OPERATION.

IMPROPER INSTALLATION OR ATTACHMENT OF EQUIPMENT OR ACCESSORIES COULD RESULT IN ELECTRIC SHOCK, SHORT-CIRCUIT, LEAKS, FIRE OR OTHER DAMAGE TO THE EQUIPMENT. BE SURE ONLY TO USE ACCESSORIES MADE BY DAIKIN WHICH ARE SPECIFICALLY DESIGNED FOR USE WITH THE EQUIPMENT AND HAVE THEM INSTALLED BY A PROFESSIONAL.











IF UNSURE OF INSTALLATION PROCEDURES OR USE, ALWAYS CONTACT YOUR DAIKIN DEALER FOR ADVICE AND INFORMATION.

The English text is the original instruction. Other languages are translations of the original instructions.

## INSTALLATION

- For installation of the air handling unit, refer to the air handling unit installation manual.
- Never operate the air conditioner with the discharge pipe thermistor (R3T), suction pipe thermistor (R2T) and pressure sensors (S1NPH, S1NPL) removed. Such operation may burn out the compressor.
- The equipment is not intended for use in a potentially explosive atmosphere.

## ACCESSORIES

		EKEQFCB	EKEQDCB
Thermistor (R1T)		—	1
Thermistor (R3T/R2T) (2.5 m cable)		2	
Insulation sheet		2	
Rubber sheet		2	
Wire to wire splice		4	6
Installation and operation manual		1	
Screw nut		7	8
Tie wrap		6	
Capacity setting adaptor		7	
Stopper (closing cup)		2	—

### Obligatory accessory

	EKEQFCB	EKEQDCB
Expansion valve kit	EKEXV	

Refer to chapter "Valve kit installation" on page 4 for installation instructions.

### Optional accessories

		EKEQFCB	EKEQDCB
Remote controller		1(*)	1

(\*) Not required for operation, only useful accessory tool for service and installation.

## NAME AND FUNCTION OF PARTS (See figure 1 and figure 2)

### Parts and components

- Outdoor unit
- Control box (EKEQFCB / EKEQDCB)
- Air handling unit (field supply)
- Controller (field supply)
- Field piping (field supply)
- Expansion valve kit

### Wiring connections

- Outdoor unit power supply
- Control box wiring (Power supply and communication between control box and outdoor unit)
- Air handling unit thermistors
- Communication between controller and control box
- Power supply and control wiring for air handling unit and controller (power supply is separate from the outdoor unit)
- Air thermistor control for air handling unit
- Remote controller (..... = for service only)

## BEFORE INSTALLATION

### Cautions for selection of the air handling unit

See table below for applicable units.

Select the air handling unit (field supply) according to the technical data and limitations mentioned below.

The design pressure of the air handling unit is at least 40 bar.

Lifetime of the outdoor unit, operation range or operation reliability may be influenced if you neglect these limitations.

Limits for outdoor unit (expansion valve kit)

Outdoor unit (class)	EKEXV kit
100	EKEXV63~125
125	EKEXV63~140
140	EKEXV80~140

Outdoor unit (class)	EKEXV kit
200	EKEXV100~250
250	EKEXV125~250

Depending on the heat exchanger, a connectable EKEXV (expansion valve kit) must be selected to these limitations.

EKEXV class	Allowed heat exchanger cooling capacity (kW)		Allowed heat exchanger heating capacity (kW)	
	Minimum	Maximum	Minimum	Maximum
63	6.3	7.8	7.1	8.8
80	7.9	9.9	8.9	11.1
100	10.0	12.3	11.2	13.8
125	12.4	15.4	13.9	17.3
140	15.5	17.6	17.4	19.8
200	17.7	24.6	19.9	27.7
250	24.7	30.8	27.8	34.7

Cooling saturated suction temperature (SST) = 6°C

Air temperature = 27°C DB/19°C WB

Superheat (SH) = 5 K

Heating saturated suction temperature (SST) = 46°C

Air temperature = 20°C DB

Subcool (SC) = 3 K

### 1 Selecting the condensing unit

Depending on necessary capacity of the combination an outdoor unit needs to be selected (see "Engineering databook" for capacity).

- Each outdoor unit can be connected to a range of air handling units.
- The range is determined by the allowed expansion valve kits.

## 2 Selecting the expansion valve

The corresponding expansion valve needs to be selected for your air handling unit. Select the expansion valve according to the above limitations.

### NOTE



- The expansion valve is an electronic type, it is controlled by the thermistors that are added in the circuit. Each expansion valve can control a range of air handling units sizes.
- The selected air handling unit must be designed for R410A.
- Extraneous substances (including mineral oils or moisture) must be prevented from getting mixed into the system.
- SST: saturated suction temperature at exit of air handling unit.

## 3 Selecting the capacity setting adaptor (see accessories)

- The corresponding capacity setting adaptor needs to be selected depending on the expansion valve.
- Connect the correct selected capacity setting adaptor to X24A (A1P). (See [figure 4](#) and [figure 6](#))

EKEXV kit	Capacity setting adaptor label (indication)
63	J71
80	J90
100	J112
125	J140
140	J160
200	J224
250	J280

**For the following items, take special care during construction and check after installation is finished**

Tick ✓ when checked	
<input type="checkbox"/>	Are the thermistors fixed firmly? Thermistor may come loose.
<input type="checkbox"/>	Is the freeze-up setting done correctly? The air handling unit may freeze up.
<input type="checkbox"/>	Is the control box fixed firmly? The unit may drop, vibrate or make noise.
<input type="checkbox"/>	Do electrical connections comply with specifications? The unit may malfunction or components may burn out.
<input type="checkbox"/>	Are wiring and piping correct? The unit may malfunction or components may burn out.
<input type="checkbox"/>	Is the unit safely grounded? Dangerous at electric leakage.

## SELECTING THE INSTALLATION SITE

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Select an installation site where the following conditions are fulfilled and that meets your customer's approval.

- The option boxes (expansion valve and electrical control box) can be installed inside and outside).
- Do not install the option boxes in or on the outdoor unit.
- Do not put the option boxes in direct sunlight. Direct sunlight will increase the temperature inside the option boxes and may reduce its lifetime and influence its operation.
- Choose a flat and strong mounting surface.
- Operating temperature of the control box is between  $-10^{\circ}\text{C}$  and  $40^{\circ}\text{C}$ .
- Keep the space in front of the boxes free for future maintenance.
- Keep air handling unit, power supply wiring and transmission wiring at least 1 m away from televisions and radios. This is to prevent image interference and noise in those electrical appliances. (Noise may be generated depending on the conditions under which the electric wave is generated, even if 1 m is kept.)
- Make sure the control box is installed horizontally. Screw nuts position must be downwards.

### Precautions

Do not install or operate the unit in rooms mentioned below.

- Where mineral oil, like cutting oil is present.
- Where the air contains high levels of salt such as air near the ocean.
- Where sulphurous gas is present such as that in areas of hot spring.
- In vehicles or vessels.
- Where voltage fluctuates a lot such as that in factories.
- Where high concentration of vapor or spray are present.
- Where machines generating electromagnetic waves are present.
- Where acidic or alkaline vapor is present.
- The option boxes must be installed with entrances downward.

# VALVE KIT INSTALLATION

## Mechanical installation

- 1 Remove the valve kit box cover by unscrewing 4x M5.
- 2 Drill 4 holes on correct position (measurements as indicated in figure below) and fix the valve kit box securely with 4 screws through the provided holes Ø9 mm.




- Make sure that the expansion valve is installed vertically.
- Make sure there is enough free space for future maintenance.

## Brazing work

For details, see manual of the outdoor unit.

- 3 Prepare the inlet/outlet field piping just in front of the connection (do **not** braze yet).



- A Inlet coming from the outdoor unit
- B Outlet to air handling unit
- C Pipe fixing clamp

- 4 Remove the pipe fixing clamp (C) by unscrewing 2x M5.
- 5 Remove the upper and lower pipe insulations.
- 6 Braze the field piping.




- Make sure to cool the filters and valve body with a wet cloth and make sure the body temperature does not exceed 120°C during brazing.
- Make sure that the other parts such as electrical box, tie wraps and wires are protected from direct brazing flames during brazing.

- 7 After brazing, put the lower pipe insulation back in place and close it with the upper insulation cover (after peeling off the liner).
- 8 Secure the pipe fixing clamp (C) in place again (2x M5).
- 9 Make sure that field pipes are fully insulated.

Field pipe insulation must reach up to the insulation you have put back in place as per procedure step 7. Make sure that there is no gap between both ends in order to avoid condensation dripping (finish the connection with tape eventually).

## Cautions for brazing

- Be sure to carry out a nitrogen blow when brazing. Brazing without carrying out nitrogen replacement or releasing nitrogen into the piping will create large quantities of oxidized film on the inside of the pipes, adversely affecting valves and compressors in the refrigerating system and preventing normal operation.
- When brazing while inserting nitrogen into the piping, nitrogen must be set to 0.02 MPa with a pressure-reducing valve (=just enough so that it can be felt on the skin).




- 1 Refrigerant piping
- 2 Part to be brazed
- 3 Taping
- 4 Hands valve
- 5 Pressure-reducing valve
- 6 Nitrogen


- For details, see manual of the outdoor unit.

## Electrical work

- 1 Open the electrical box cover (A).
- 2 Push out **ONLY** the second lower wire intake hole (B) from inside to outside. Do not damage the membrane.
- 3 Pass valve cable (with wires Y1 ... Y6) from the control box through that membrane wire intake hole and connect the cable wires into the terminal connector (C) following instructions as described in step 4. Route the cable out of the valve kit box according to figure below and fix with the tie wrap (D). See "Electric wiring work" on page 5 for more details.



- Use a small screwdriver and follow indicated instructions for connecting cable wires into the terminal connector according to the wiring diagram.



- Make sure that field wiring and insulation is not squeezed when closing the valve kit box cover.
- Close the valve kit box cover (4x M5).

## INSTALLATION OF THE ELECTRICAL CONTROL

**BOX** (See [figure 4](#) and [figure 6](#))

- Control box
- Hanger brackets
- Main PCB
- Transformer
- Terminal
- PCB (for voltage conversion)
- PCB (power supply)
- Magnetic relay (operation / compressor ON/OFF)
- Magnetic relay (error status)
- Magnetic relay (fan)
- Magnetic relay (defrost)
- Optional PCB (KRP4)

### Mechanical installation


- Fix the control box with its hanger brackets to the mounting surface.  
Use 4 screws (for holes of Ø6 mm).
- Open the lid of the control box.
- For electrical wiring: refer to paragraph "Electric wiring work" on [page 5](#).
- Install the screw nuts.
- Close the unnecessary openings with stoppers (closing cups).
- Close the lid securely after installation to ensure that the control box is watertight.

## ELECTRIC WIRING WORK

- All field supplied parts and materials and electric works must be conform to local codes.
- Use copper wire only.
- All wiring must be performed by an authorized electrician.
- A main switch or other means for disconnection, having a contact separation in all poles, must be incorporated in the fixed wiring in accordance with relevant local and national legislation.
- Refer to the installation manual attached to the outdoor unit for the size of power supply electric wire connected to the outdoor unit, the capacity of the circuit breaker and switch, wiring and wiring instructions.
- Attach the earth leakage circuit breaker and fuse to the power supply line.

### Connection of the wires inside the control box

- For connection to outdoor unit and to controller (field supply):  
Pull the wires inside through the screw nut and close the nut firmly in order to ensure a good pull relieve and water protection.
- The cables require an additional pull-relief. Strap the cable with the installed tie wrap.



### Precautions

- Thermistor cable and remote controller wire should be located at least 50 mm away from power supply wires and from wires to the controller. Not following this guideline may result in malfunction due to electrical noise.
- Use only specified wires, and tightly connect wires to the terminals. Keep wiring in neat order so that it does not obstruct other equipment. Incomplete connections could result in overheating, and in worse case electric shock or fire.



## Connecting the wiring: EKEQFCBV3

- Connect the wires to the terminal board according to the wiring diagram in figure 3. See figure 4 for wiring intake in the control box. The wiring intake hole indication H1 refers to the H1 cable of the corresponding wiring diagram.

- Connect cables according to specifications of the next table.



Take special precaution for connection to the controller (field supply). Do not miswire the output signals nor the input signal (ON/OFF). This mistake could damage the entire system.

Table connection and application

	Description	Connect to	Type of cable	Cross section (mm <sup>2</sup> ) <sup>(*)</sup>	Maximum length (m)	Specifications	
L, N, earth	Power supply	Power supply	H05VV-F3G2.5	2.5	—	Power supply 230 V 1~ 50 Hz	
Y1~Y6	Expansion valve connection	Expansion valve kit	LIYCY3 x 2 x 0.75	0.75	20	Digital output 12 V DC	
R1,R2	Thermistor R2T (liquid pipe)	—	H05VV-F2 x 0.75		Standard 2.5 Maximum 20	100	Analog input 16 V DC
R3,R4	Thermistor R3T (gas pipe)						
P1,P2	Remote controller (optional)						
F1,F2	Communication to outdoor unit	Outdoor unit					Communication line 16 V DC
T1,T2	ON/OFF	Controller field supply	LIYCY4 x 2 x 0.75		(t)		Digital input 16 V DC
C1,C2	Error signal						Digital output: voltage free. Maximum 230 V, maximum 0,5 A
C3,C4	Operation signal <sup>(‡)</sup>						Analog input: 0~10 V
C5,C6	Capacity step <sup>(#)</sup>						
C7,C8	Fan signal	Air handling unit fan field supply	H05VV-F3G2.5		2.5	—	Digital output: voltage free. Maximum 230 V, maximum 2 A
C9,C10	Defrost signal	Controller field supply	LIYCY4 x 2 x 0.75	0.75	(t)	Digital output: voltage free. Maximum 230 V, maximum 0,5 A	

(\*) Recommended size (all wiring must comply with local codes).





(†) The maximum length depends on the external device that is connected (controller/relay,...)

(‡) Operation signal: indicates compressor operation.

(#) Only necessary for capacity controlled system.

## Wiring diagram

A1P.....Printed circuit board  
A2P.....Printed circuit board (for voltage conversion)  
A3P.....Printed circuit board (power supply)  
F1U.....Fuse (250 V, F5A)(A1P)  
F2U.....Fuse (250 V, T1A)(A3P)  
F3U.....Field fuse  
HAP.....Light emitting diode (service monitor-green)  
K2R.....Magnetic relay (error status)  
K3R.....Magnetic relay (operation / compressor ON/OFF)  
K4R.....Magnetic relay (fan)  
K5R.....Magnetic relay (defrost signal)  
K1R,KAR,KPR....Magnetic relay  
Q1DI.....Earth leakage breaker  
R2T.....Thermistor (liquid)  
R3T.....Thermistor (gas)  
R5.....Resistance (120 Ω)  
R6.....Capacity adaptor  
T1R.....Transformer (220 V/21.8 V)  
X1M,X2M,X3M ...Terminal block  
Y1E.....Electronic expansion valve  
X1M-C7/C8.....Output: fan ON/OFF  
X1M-C9/C10.....Output: defrost signal  
X1M-R1/R2.....Thermistor liquid  
X1M-R3/R4.....Thermistor gas  
X1M-Y1~6 .....Expansion valve  
X2M-C1/C2.....Output: error status

X2M-C3/C4..... Output: operation / compressor ON/OFF  
X2M-C5/C6..... Input: 0-10 V DC capacity control  
X2M-F1/F2..... Communication outdoor unit  
X2M-P1/P2..... Communication remote controller  
X2M-T1/T2..... Input: ON/OFF  
..... Field wiring  
L..... Live  
N..... Neutral  
..... Connector  
○..... Wire clamp  
..... Protective earth (screw)  
—..... Separate component  
..... Optional accessory  
BLK..... Black  
BLU..... Blue  
BRN..... Brown  
GRN..... Green  
GRY..... Gray  
ORG..... Orange  
PNK..... Pink  
RED..... Red  
WHT..... White  
YLW..... Yellow

## Connecting the wiring: EKEQDCBV3




- Connect the wires to the terminal board according to the wiring diagram in figure 5. See figure 6 for wiring intake in the control box. The wiring intake hole indication H1 refers to the H1 cable of the corresponding wiring diagram.
- Connect cables according to specifications of the next table.

Table connection and application

	Description	Connect to	Type of cable	Cross section (mm <sup>2</sup> ) <sup>(*)</sup>	Maximum length (m)	Specifications
L, N, earth	Power supply	Power supply	H05VV-F3G2.5	2.5	—	Power supply 230 V 1~ 50 Hz
Y1~Y6	Expansion valve connection	Expansion valve kit	LIYCY3 x 2 x 0.75	0.75	20	Digital output 12 V DC
R1,R2	Thermistor R2T (liquid pipe)	—	H05VV-F2 x 0.75		Standard: 2.5 Max.: 20	Analog input 16 V DC
R3,R4	Thermistor R3T (gas pipe)					
R5,R6	Thermistor R1T (air)					
P1,P2	Remote controller					
F1,F2	Communication to outdoor unit	Outdoor unit			100	Communication line 16 V DC
T1,T2	ON/OFF	Controller field supply	LIYCY4 x 2 x 0.75	Optional connection: when the function of the switch box needs to be extended: see KRP4A51 for details of settings and instructions.	—	Digital input 16 V DC
—	Capacity step					
—	Error signal					
—	Operation signal					
C1,C2	Fan signal	Air handling unit fan field supply	H05VV-F3G2.5	2.5	—	Digital output: voltage free. Maximum 230 V, maximum 2 A

(\*) Recommended size (all wiring must comply with local codes).

## Wiring diagram

A1P .....	Printed circuit board		Field wiring
A2P .....	Printed circuit board (option KRP4)	L .....	Live
F1U .....	Fuse (250 V, F5A)(A1P)	N .....	Neutral
F3U .....	Field fuse	 .....	Connector
HAP .....	Light emitting diode (service monitor-green)	o .....	Wire clamp
K1R .....	Magnetic relay		Protective earth (screw)
K4R .....	Magnetic relay (fan)	— — — .....	Separate component
Q1DI .....	Earth leakage breaker	==:== .....	Optional accessory
R1T .....	Thermistor (air)	BLK .....	Black
R2T .....	Thermistor (liquid)	BLU .....	Blue
R3T .....	Thermistor (gas)	BRN .....	Brown
R7 .....	Capacity adaptor	GRN .....	Green
T1R .....	Transformer (220 V/21.8 V)	GRY .....	Gray
X1M,X3M .....	Terminal block	ORG .....	Orange
Y1E .....	Electronic expansion valve	PNK .....	Pink
X1M-C1/C2 .....	Output: fan ON/OFF	RED .....	Red
X1M-F1/F2 .....	Communication outdoor unit	WHT .....	White
X1M-P1/P2 .....	Communication remote controller	YLW .....	Yellow
X1M-R1/R2 .....	Thermistor liquid		
X1M-R3/R4 .....	Thermistor gas		
X1M-R5/R6 .....	Thermistor air		
X1M-T1/T2 .....	Input: ON/OFF		
X1M-Y1~6 .....	Expansion valve		

# INSTALLATION OF THERMISTORS

## Refrigerant thermistors


### Location of the thermistor

A correct installation of the thermistors is required to ensure a good operation:

1. Liquid (R2T)  
Install the thermistor behind the distributor on the coldest pass of the heat exchanger (contact your heat exchanger dealer).
2. Gas (R3T)  
Install the thermistor at the outlet of the heat exchanger as close as possible to the heat exchanger.

Evaluation must be done to check if the air handling unit is protected against freeze-up.


Execute test operation and check for freeze-up.



- 1 Liquid R2T
- 2 Gas R3T

### Installation of the thermistor cable


- 1 Put the thermistor cable in a separate protective tube.
- 2 Always add a pull-relief to the thermistor cable to avoid strain on the thermistor cable and loosening of the thermistor. Strain on the thermistor cable or loosening of the thermistor may result in bad contact and incorrect temperature measurement.




### Fixation of the thermistor



- Put the thermistor wire slightly down to avoid water accumulation on top of the thermistor.




- Make good contact between thermistor and air handling unit. Put the top of the thermistors on the air handling unit, this is the most sensitive point of the thermistor.




- 1 Most sensitive point of the thermistor
- 2 Maximize the contact


- 1 Fix the thermistor with insulating aluminum tape (field supply) in order to ensure a good heat transference.




- 2 Put the supplied piece of rubber around the thermistor (R2T/R3T) in order to avoid loosening of the thermistor after some years.



- 3 Fasten the thermistor with 2 tie wraps.



- 4 Insulate the thermistor with the supplied insulation sheet.



### Air thermistor (only for EKEQDCB)

The air thermistor (R1T) can be installed either in the room that needs temperature control or in the suction area of the air handling unit.



For room temperature control the delivered thermistor (R1T) can be replaced by an optional remote sensor kit KRCS01-1(A) (to be ordered separately).

## Installation of longer thermistor cable (R1T/R2T/R3T)

The thermistor is supplied with a standard cable of 2.5 m. This cable can be made longer to up to 20 m.

### Install the longer thermistor cable with the delivered wire to wire splices

- 1 Cut the wire or bundle the remainder of the thermistor cable.  
Keep at least 1 m of the original thermistor cable.  
Do not bundle the cable inside the control box.
- 2 Strip the wire  $\pm 7$  mm at both ends and insert these ends into the wire to wire splice.
- 3 Pinch the splice with the correct crimp tool (pliers).
- 4 After connection, heat up the shrink-insulation of the wire to wire splice with a shrink-heater to make a water tight connection.
- 5 Wrap electrical insulation tape around the connection.
- 6 Put a pull-relief in front of and behind the connection.



- The connection must be made on an accessible location.
- To make the connection waterproof, the connection can also be made in a switch box or connector box.
- The thermistor cable should be located at least 50 mm away from power supply wire. Not following this guideline may result in malfunction due to electrical noise.

## REFRIGERANT PIPING WORK



All field piping must be provided by a licensed refrigeration technician and must comply with the relevant local and national codes.

- For refrigerant piping of outdoor unit, refer to the installation manual supplied with the outdoor unit.
- Follow the outdoor unit specifications for additional charging, piping diameter and installation.
- The maximum allowed piping length depends on the connected outdoor model.

## TEST OPERATION

Before executing "test operation" as well as before operating the unit, you must check the following:

- Refer to the section of "[For the following items, take special care during construction and check after installation is finished](#)" on page 3.
- After finishing the construction of refrigerant piping, drain piping and electric wiring, conduct test operation accordingly to protect the unit.
- Open the gas side stop valve.
- Open the liquid side stop valve.

### Executing the test operation

- 1 Close the contact T1/T2 (ON/OFF).
- 2 Confirm function of the unit according to the manual and check if the air handling unit has collected ice (freeze-up).  
If the unit collects ice: see "[Troubleshooting](#)" on page 11.
- 3 Confirm that the fan of the air handling unit is ON.



- In case of poor distribution in the air handling unit, 1 or more passes of the air handling unit may freeze-up (collect ice) → put the thermistor (R2T) on this position.
- Depending on operation conditions (e.g.: outdoor ambient temperature) it is possible that the settings must be changed after commissioning.

## OPERATION AND MAINTENANCE

If T1/T2 is applicable:

- Closing the T1/T2 signal starts operation of the air handling unit.
- Opening the T1/T2 signal stops operation of the air handling unit.

## WHAT TO DO BEFORE OPERATION



- Before initiating operation, contact your dealer to get the operation manual that corresponds to your system.
- Refer to the dedicated manual of the controller (field supply) and air handling unit (field supply).
- Make sure that the air handling unit fan is ON when the outdoor unit is in normal operation.

### Field settings for EKEQDCB

Refer to the installation and service manuals of both the outdoor unit and the remote controller.

### Field settings for EKEQFCB

When changing the settings:

- 1 Make the required settings.
- 2 Turn power OFF.
- 3 Remove the remote controller after servicing and checking the system in cooling mode. Operating the remote controller may disturb the normal operation of the system.
- 4 Do not change T1/T2 during power failure.
- 5 Put power of indoor and outdoor unit ON.

Setting the temperature control system

Mode No.	Code No.	Description of setting
13(23)-0	01	Operation with 0-10 V capacity control (= factory setting)
	02	Operation with fixed $T_e/T_c$ temperature control

$T_e$  or SST = evaporating temperature or saturated suction temperature.  $T_c$  = condensing temperature.

## Operation with 0–10 V capacity control


The 0–10 V input is only used for this system of operation and is the base of the capacity control.

This system needs a field supplied controller with a temperature sensor. The temperature sensor can be used to control any temperature:

- Suction air of the air handling unit
- Room air
- Discharge air of the air handling unit

Program the field supplied controller to generate a 0–10 V signal within conditions as listed. Also refer to the graphic and further data in this paragraph for more details.

- When target temperature is reached: 5 V
- When lower refrigerant temperature is needed: 5–10 V
- When higher refrigerant temperature is needed: 0–5 V



**A** Controller voltage output to EKEQFCB

■ Temperature increase area

■ Temperature decrease area

Voltage output = linear function with  $\Delta T$

$\Delta T$  = [actual measured temperature] – [target temperature]  
When  $\Delta T=0$ , the target temperature is reached.

$\Delta T_{max}$  = maximum temperature variation as defined by installation  
Recommended value for  $\Delta T_{max}=[2^{\circ}\text{C}\sim 5^{\circ}\text{C}]$ .

Voltage output from controller (field supply)	Cooling capacity	Heating capacity
0 V	strong decrease	strong increase
2.5 V	decrease	increase
5 V	constant	constant
7.5 V	increase	decrease
10 V	strong increase	strong decrease

## Operation with fixed $T_e/T_c$ temperature control

The evaporating temperature ( $T_e$ )/condensing temperature ( $T_c$ ) at which the application has to operate can be set by code numbers as listed below.

Mode No.	Code No.	Description of setting <sup>(*)</sup>
13(23)–1	01	$T_e = 5^{\circ}\text{C}$
	02	$T_e = 6^{\circ}\text{C}$
	03	$T_e = 7^{\circ}\text{C}$
	04	$T_e = 8^{\circ}\text{C}$ (factory setting)
	05	$T_e = 9^{\circ}\text{C}$
	06	$T_e = 10^{\circ}\text{C}$
	07	$T_e = 11^{\circ}\text{C}$
	08	$T_e = 12^{\circ}\text{C}$
13(23)–2	01	$T_c = 43^{\circ}\text{C}$
	02	$T_c = 44^{\circ}\text{C}$
	03	$T_c = 45^{\circ}\text{C}$
	04	$T_c = 46^{\circ}\text{C}$ (factory setting)
	05	$T_c = 47^{\circ}\text{C}$
	06	$T_c = 48^{\circ}\text{C}$
	07	$T_c = 49^{\circ}\text{C}$

<sup>(\*)</sup> Depending on the operating temperature condition or on selection of the air handling unit, operation or safety activation of the outdoor unit may take priority and actual  $T_e/T_c$  will be different from the set  $T_e/T_c$ .

## Operation setting in case of power failure



Measures must be taken to ensure that after power failure, T1/T2 is according to the setting of your preference. Neglecting this caution will result in improper operation.

Mode No.	Code No.	Description of setting
12(22)–5	01	T1/T2 must be open at power restore. <sup>(*)</sup>
	02	After power failure, the status of T1/T2 must remain identical to the initial T1/T2 status prior to the power failure.

<sup>(\*)</sup> After power failure, T1/T2 must be changed to open (no cooling/heating requested).

## OPERATION AND DISPLAY SIGNALS

For EKEQF only			
Output	C1/C2 error signal	Error: Closed	Abnormal operation on condenser or control system
			Power failure
	No error: Open		Normal operation
			T1/T2 is open: no error detection anymore
	C3/C4 operation signal	Closed	Compressor not operating
		Open	Compressor operating
C7/C8 fan output	Open	Fan off	
	Closed	Fan on	
C9/C10 defrost output	Open	No defrost operation	
	Closed	Defrost operation	
Input	C5/C6: capacity step	0–10 V	Only necessary for field setting 13(23)–0 = 01 0–10 V capacity control(*)
	T1/T2(†)	Open	No cooling/heating requested
Closed		Cooling/heating requested	

(\*) Refer to paragraph "Operation with 0–10 V capacity control" on page 10.

(†) See field setting 12(22)–5.

For EKEQD only			
Output	C1/C2 fan output	Open	Fan off
		Closed	Fan on
Input	T1/T2(*)	Open	No cooling/heating requested
		Closed	Cooling/heating requested

(\*) See field setting 12(22)–5.



- The fan of the air handling unit must operate before cooling operation is required to the outdoor unit.
- When the operation signal is activated, the air handling unit and fan must operate. Failure to this will cause a safety to operate or freezing up of the air handling unit.

## TROUBLESHOOTING

To set up the system and make trouble shooting possible, it is required to connect the remote controller to the option kit.

### Not a malfunction of the air conditioner

#### The system does not operate

- The system does not restart immediately after the cooling/heating is requested. If the operation lamp lights, the system is in normal operating condition. It does not restart immediately because one of its safety devices actuates to prevent the system from being overloaded. The system will turn on again automatically after 3 minutes.
- The system does not restart immediately after the power supply is turned on. Wait 1 minute until the micro computer is prepared for operation.

## Trouble shooting

If one of the following malfunctions occurs, take the measures shown below and contact your dealer.

The system must be repaired by a qualified service person.

- If a safety device such as a fuse, a breaker, or an earth leakage breaker frequently actuates, or ON/OFF switch does not properly work. Turn off the main power switch.
- If the display TEST, the unit number and the operation lamp flash and the malfunction code appears; Notify your dealer and report the malfunction code.

If the system does not operate properly, and none of the above mentioned malfunctions is evident, investigate the system according to the following procedures.

#### If the system does not operate at all

- Check if there is a power failure. Wait until power is restored. If power failure occurs during operation, the system automatically restarts immediately after the power supply recovers.
- Check if the fuse has blown or breaker has been tripped. Change the fuse or set the breaker.

#### If the system stops operating after operation is complete

- Check if the air inlet or outlet of outdoor or air handling unit is blocked by obstacles. Remove the obstacle and make it well-ventilated.
- Check if the air filter is clogged. Ask a qualified service person to clean the air filter.
- The error signal is given and the system stops. If the error resets after 5-10 minutes, the unit safety device was activated but the unit restarted after evaluation time. If the error persists, contact your dealer.

#### If the system operates but it does not sufficiently cool/heat

- Check if the air inlet or outlet of the air handling unit or the outdoor unit is blocked with obstacles. Remove the obstacle and make it well-ventilated.
- Check if the air filter is clogged. Ask a qualified service person to clean the air filter.
- Check if the doors or the windows are open. Shut doors or windows to prevent wind from coming in.
- Check if direct sunlight enters the room. Use curtains or blinds.
- Check if there are too many inhabitants in the room. Cooling effect decreases if heat gain of the room is too large.
- Check if the heat source of the room is excessive. Cooling effect decreases if heat gain of the room is too large.

#### The air handling unit is freezing up

- The liquid thermistor (R2T) is not put on the coldest position and part of the air handling unit is freezing up. Thermistor must be put on the coldest position.
- The thermistor has come loose. The thermistor must be fixed.
- The air handling unit fan is not operating continuously. When the outdoor unit stops operating, the air handling unit fan must continue operation to melt the ice that was accumulated during outdoor unit operation. Ensure that the air handling unit fan keeps operating.

In these cases, contact your dealer.





\*4PW52446-1 B 0000000\*

Copyright 2029 Daikin

**DAIKIN EUROPE N.V.**

Zandvoordestraat 300, B-8400 Oostende, Belgium

4PW52446-1B 07.2010