部番 ITEM NO.	品番	部品管理記号 ITEM MARK	※図面番号 DWG NO.	※※一式分個数 QUANT.	名称 PART NAME	材質 MATERIAL	記事 REMARK	CCM	補用
1		F	本図ニヨル THIS DWG	1	据付説明書(裏)(英語) INSTALLATION MANUAL(BACK SIDE)	再生上質紙 WOOD FREE PAPER	55kg/連 55kg/REAM	2	

第3角法 3RD ANGLE PROJECTION

En. 英

4 ELECTRIC WIRING

① First, wire between the indoor and outdoor units, and then to the separate power sources, and finally between the indoor units and the remote controllers. Then, check if they operate properly.
(If wiring for group control by remote controller, check crosswires.)
For details, see the installation manual of the indoor and outdoor units.

② Next, wire between outside units such as the central control monitor, etc. and make the necessary settings.
For details, see Wiring to outside units (central control monitor) .

Wiring to indoor units



Make connections as shown above, using the attached relay harnesses (1) and (2).
- Connect relay harness (1) to the connector (X35A or X18A) on the indoor unit PC board.
- Relay harness (2) has no polarity. Connect it to terminals P1 and P2 on the transmission wiring terminal board inside the indoor unit Electric parts box.

Wiring to outside units (central control monitor)

1. Remote control input (operation control)

Wire as described below. Wiring differs depending on whether using a voltage or no-voltage input.

For voltage input

Set the changeover switch (SS1) to "VOLT". (Factory set : VOLT)

Connect the control input to the common contact (no polarity).

Use an external ⎓ 12 - 24 V power supply. Each contact requires approximately 10 mA, therefore carefully select power supply capacity.



For NON VOLT input

Set the changeover switch (SS1) to "NON VOLT".





(Wiring specifications)
Wiring ... Sheathed vinyl cord or cable
Gauge ... 0.18 ~ 1.25 mm²
Length ... Max. 150 m

〈NOTE〉
Keep transmission wiring away from power supply wiring to avoid malfunctions.

2. Setting the control mode selector switch (RS1)

Using the control mode selector switch (RS1), select the control mode as described below.

(Factory set)
"0" position

① For specifying individual display

Position	Function
0	Individual display (input ignored)

② When operating the unit with constant input at input A

Position	Function	When input A is ON	When input A is OFF
1	ON/OFF control impossible by remote controller	Operation (normally ON/OFF control impossible by remote controller)	OFF + ON/OFF control impossible by remote controller
2	Centralized	Operation + ON/OFF control possible by remote controller	
3	OFF control possible by remote controller	Operation + OFF control possible by remote controller (ON control impossible by remote controller)	
4	ON/OFF control possible by remote controller	ON/OFF control possible by remote controller (Operation impossible by optional controller)	

〈Note〉
- Input B is for forced ON/OFF input. When input B is ON, OFF control is possible but ON/OFF control by the remote controller is impossible, and input A is igored. When it is OFF, input A is ignored even if selected. It is necessary to reselect input A.

③ When operating the unit using instantaneous input at input A
(Use a instantaneous input of 200 msec or longer ON time.)

Position	Function	Input A	Input B capacity
5	ON/OFF control impossible by remote controller	Turns OFF system with On input Turns ON system with ON input	Input B is for forced OFF input (when ON, OFF control is possible but ON/OFF control by remote controller is impossible, and input A is ignored).
6	Individual	Turns OFF system with ON input Turns ON system with ON input (Normally ON/OFF control possible by remote controller)	

★ For thermostat control using input B

Position	When input A is ON	When input B is ON
C	ON/OFF control impossible by remote controller (Same as position 5)	Forced thermostat OFF command
D		Energy saving command (✻)
E	Individual (Same as position 6)	Forced thermostat OFF command
F		Energy saving command (✻)

- Forced thermostat OFF command
  Indoor unit fan only operates.
- Energy saving command (✻)
  The indoor unit operates at 2°C higher (cooling)/lower(heating) the set temperature.

〈Notes〉
- In such case, even if input A is ON, thermostat control is turned OFF, and all units in the same group will stop.

(✻) With Sky Air units, the forced thermostat OFF command is generated even when position D and F are selected.

④ When operating the unit using instantaneous input at input A and B
(Use an instantaneous input of 200 msec or longer ON time).

Position	Function	When input A is ON	When input A is OFF
7	ON/OFF control impossible by remote controller	Operation (normally ON/OFF control impossible by remote controller)	OFF + ON/OFF control impossible by remote controller
8	Centralized	Operation + ON/OFF control possible by remote controller	
9	OFF control possible by remote controller	Operation + OFF control possible by remote controller (ON control impossible by remote controller)	
A	ON/OFF control possible by remote controller	ON/OFF control possible by remote controller (Operation impossible by optional controller)	
B	Individual	Operation (normally ON/OFF control possible by remote controller)	OFF (normally ON/OFF control possible by remote controller)

〈Notes〉
- When set to position 7-A, and using the constant mode for input B, forced stop capacity is enabled (input A is ignored).
- At position B, the constant mode for input B is not used.

3. Temperature setting input

To enable temperature setting from both the optional controller and remote controller, set SS2 to "POSSIBLE". (Factory setting : POSSIBLE)
POSSIBLE: Enables temperature setting by both the optional controller and remote controller. (Engages individual control.)
IMPOSSIBLE: Enables temperature setting from the optional controller only. (The remote controller cannot be used to set temperature.)



Never apply voltage to terminals A⁺ or A⁻ for any reason whatsoever.

Temperature setting corresponds to resistance values in the range of 0 to 135Ω as shown below.

Temperature setting (˚C)	16	17	18	19	20	21	22	23	24
Resistance (Ω)	0.0 ~ 3.4	5.0 ~ 11.6	13.8 ~ 20.0	22.4 ~ 28.4	31.0 ~ 36.4	39.4 ~ 44.8	48.2 ~ 52.8	56.6 ~ 61.2	65.2 ~ 69.4

Temperature setting (˚C)	25	26	27	28	29	30	31	32
Resistance (Ω)	73.8 ~ 77.8	82.4 ~ 85.8	91.0 ~ 94.0	99.4 ~ 102.2	108.6 ~ 110.4	117.2 ~ 119.2	125.8 ~ 127.4	134.2 ~ 140.0

〈Note〉 Line resistance included in above figures.

(Wiring specifications)
Wiring ... Sheathed vinyl cord
Gauge ... 1.25 ~ 2.00 mm²
Length ... Max. 70 m

〈NOTE〉
Keep transmission wiring away from power supply wiring to avoid malfunctions.

4. Cancelling display signals

Operation output terminals (W1 and W2) and error output terminals (W3 and W4) are no-voltage normally constant contacts.

(Allowed electric current per contact is between 10 mA and 3 A.)

Normal operation output (Ry1)
ON when the indoor unit is operating normally.

Error output (Ry2)
ON when the indoor unit stops because of malfunction or when a transmission error occurs between the adaptor and the indoor unit.



〈 NOTE 〉
If using a 220 or 240 V power supply, keep transmission wires away from incoming power supply wiring.

Display output is as described below.

Output	Both Ry1 and Ry2 OFF	Only Ry1 ON	Only Ry2 ON
Display	OFF	Normal operation	System stopped due to malfuction or transmission error generated between adaptor and indoor unit

1PA59890-1F

注) 1. 紙ノ大キサハ420×594(A2サイズ)トスルコト。
2. 文字及ビイラストハ、全テ黒色トスル。
3. 字体及ビレイアウトハ本図ニ準ズルコト。
4. 校正ノ段階デ版下ヲ提供シ、設計ノ確認ヲ得ルコト。
5. 本図ハ1PA59889-1ノ裏面ニ印刷スルコト。
6. ソノ他ノ特記外ハ、AS303004(最新ノモノ)ニヨルコト。

NOTES) 1. SIZE OF PAPER : 420 × 594 (A2 SIZE)
2. USE BLACK COLOR FOR ALL OF LETTERS AND ILLUSTRATIONS.
3. SEE THIS DWG. TYPES AND LAYOUT.
4. OBTAIN APPROVAL OF BLOCK COPY FROM THE DESIGN DEPT. AT PROOF READING.
5. PRINT THIS DWG ON THE BACK SIDE OF THE INSTALLATION MANUAL SHOWN IN THE DWG NO. 1PA59889-1.
6. SEE AS303004 (LATEST) UNLESS OTHERWISE SPECIFED.

適合規格欄 AS303004

冷媒圧ヲ受ケナイ部品	⓪
DP2.8	1
DP3.3	2
DP4.14	3
ソノ他圧力	9 4

共用先	設・区	配布
住・本部		
汎・本部		
セ・本部		
圧・開発		

登録DAPICS (コードニ○印ヲ記入)
⓪・10・20・50・60・70

配布先
Ⓚ・G・N・S・B
Ⓐ・Ⓚ・Ⓕ

部番 ITEM	塗装箇所 PLACE	塗装種別 PAINT	素地 FOUND	工程 PROCESS	仕上色 COLOR	艶 GLOSS	塗装(マタハ備考) REMARK

表ニナイ寸法ハJIS B 0405 TOLERANCE NOT INDICATED AS303004

	P
A 全面	BR082887 08/08/05 ⑨ 図面改正依頼ニヨル 重多 BY REQUEST TO CHANGE THE DRAWING 江川
C級	補用互換性 : ⑨・無 INTERCHANGEABILITY YES NO DS019
A 1 D級	BR082740 08/07/16 ⑨ 誤記訂正 重多 CORRECTION OF ERRORS 伊勢田
	補用互換性 : ⑨・無 INTERCHANGEABILITY YES NO MT010

KRP4A51
据付説明書(裏)(英語)
INSTALLATION MANUAL (BACK SIDE)(En.)

作図沿革 DESIGNED DETAILS	1PA59590Cハ旧図トスル	試作・生産 PILOT PRODUCTION
ダイキン工業株式会社 DAIKIN INDUSTRIES, LTD	尺度 SCALE	
承認 APPROVED	照査 CHECKED	設計 DESIGNED	製図 DRAWN
沢井	平居		岩本

作成日 DATE YR 97 MO 12 DA 5
部品コード PART CODE JA942500
1PA59890JF